

# checkCIF/PLATON report

Structure factors have been supplied for datablock(s) bian873

THIS REPORT IS FOR GUIDANCE ONLY. IF USED AS PART OF A REVIEW PROCEDURE FOR PUBLICATION, IT SHOULD NOT REPLACE THE EXPERTISE OF AN EXPERIENCED CRYSTALLOGRAPHIC REFEREE.

No syntax errors found.    CIF dictionary    Interpreting this report

## Datablock: bian873

---

Bond precision: Bi-Pd = 0.0001 Å                  Wavelength=1.34139

Cell:                        a=6.5784(2)                b=6.5784(2)                c=6.5784(2)  
                              alpha=90                        beta=90                        gamma=90

Temperature:                150 K

	Calculated	Reported
Volume	284.68(3)	284.68(3)
Space group	F -4 3 m	F -4 3 m
Hall group	F -4 2 3	F -4 2 3
Moiety formula	Bi Pd Yb	0.042(Bi24 Pd24 Yb24)
Sum formula	Bi Pd Yb	Bi Pd Yb
Mr	488.42	488.42
Dx,g cm-3	11.396	11.396
Z	4	4
Mu (mm-1)	218.768	218.766
F000	796.0	796.0
F000'	745.35	
h,k,lmax	8,8,8	8,8,8
Nref	48[ 29 ]	51
Tmin,Tmax	0.013,0.038	0.021,0.122
Tmin'	0.001	

Correction method= # Reported T Limits: Tmin=0.021 Tmax=0.122  
AbsCorr = MULTI-SCAN

Data completeness= 1.76/1.06                  Theta(max)= 59.895

R(reflections)= 0.0344( 51)                  wR2(reflections)= 0.0764( 51)

S = 1.425                        Npar= 6

---

The following ALERTS were generated. Each ALERT has the format  
**test-name\_ALERT\_alert-type\_alert-level**.

Click on the hyperlinks for more details of the test.

---

### Alert level B

PLAT090_ALERT_3_B Poor Data / Parameter Ratio (Zmax > 18) .....	5.17 Note
PLAT111_ALERT_2_B ADDSYM Detects New (Pseudo) Centre of Symmetry .	100 %Fit
PLAT112_ALERT_2_B ADDSYM Detects New (Pseudo) Symm. Elel	4 100 %Fit
PLAT112_ALERT_2_B ADDSYM Detects New (Pseudo) Symm. Elel	4 100 %Fit
PLAT112_ALERT_2_B ADDSYM Detects New (Pseudo) Symm. Elel	4 100 %Fit
PLAT113_ALERT_2_B ADDSYM Suggests Possible Pseudo/New Space Group	Fm-3m Check

---

### Alert level C

STRVA01_ALERT_4_C Flack test results are ambiguous.	
From the CIF: _refine_ls_abs_structure_Flack 0.410	
From the CIF: _refine_ls_abs_structure_Flack_su 0.050	
PLAT031_ALERT_4_C Refined Extinction Parameter Within Range .....	3.000 Sigma

---

### Alert level G

ABSMU01_ALERT_1_G Calculation of _exptl_absorpt_correction_mu	
not performed for this radiation type.	
PLAT004_ALERT_5_G Polymeric Structure Found with Maximum Dimension	3 Info
PLAT042_ALERT_1_G Calc. and Reported Moiety Formula Strings Differ	Please Check
PLAT083_ALERT_2_G SHELXL Second Parameter in WGHT Unusually Large	14.01 Why ?
PLAT720_ALERT_4_G Number of Unusual/Non-Standard Labels .....	3 Note
PLAT870_ALERT_4_G ALERTS Related to Twinning Effects Suppressed ..	! Info
PLAT961_ALERT_5_G Dataset Contains no Negative Intensities .....	Please Check

---

0 **ALERT level A** = Most likely a serious problem - resolve or explain

6 **ALERT level B** = A potentially serious problem, consider carefully

2 **ALERT level C** = Check. Ensure it is not caused by an omission or oversight

7 **ALERT level G** = General information/check it is not something unexpected

2 ALERT type 1 CIF construction/syntax error, inconsistent or missing data

6 ALERT type 2 Indicator that the structure model may be wrong or deficient

1 ALERT type 3 Indicator that the structure quality may be low

4 ALERT type 4 Improvement, methodology, query or suggestion

2 ALERT type 5 Informative message, check

---

---

It is advisable to attempt to resolve as many as possible of the alerts in all categories. Often the minor alerts point to easily fixed oversights, errors and omissions in your CIF or refinement strategy, so attention to these fine details can be worthwhile. In order to resolve some of the more serious problems it may be necessary to carry out additional measurements or structure refinements. However, the purpose of your study may justify the reported deviations and the more serious of these should normally be commented upon in the discussion or experimental section of a paper or in the "special\_details" fields of the CIF. checkCIF was carefully designed to identify outliers and unusual parameters, but every test has its limitations and alerts that are not important in a particular case may appear. Conversely, the absence of alerts does not guarantee there are no aspects of the results needing attention. It is up to the individual to critically assess their own results and, if necessary, seek expert advice.

### **Publication of your CIF in IUCr journals**

A basic structural check has been run on your CIF. These basic checks will be run on all CIFs submitted for publication in IUCr journals (*Acta Crystallographica*, *Journal of Applied Crystallography*, *Journal of Synchrotron Radiation*); however, if you intend to submit to *Acta Crystallographica Section C* or *E* or *IUCrData*, you should make sure that full publication checks are run on the final version of your CIF prior to submission.

### **Publication of your CIF in other journals**

Please refer to the *Notes for Authors* of the relevant journal for any special instructions relating to CIF submission.

---

**PLATON version of 22/03/2021; check.def file version of 19/03/2021**

### Datablock bian873 - ellipsoid plot

